

CARE AND SAFETY GUIDELINES

- ◆ Store in a cool dry environment. Prolonged exposure to direct sunlight, severe hot, cold, or damp conditions can weaken the components of this product.
- ◆ Review the safety instructions and all components before beginning use. If the components of Versa-Band show signs of wear and tear, discontinue use and replace any damaged or worn components immediately.
- ◆ Always check that components are securely and properly attached to the Main Body (fig. A) and D-Rings (fig. B). Always test that anchor is set securely before applying weight. Do not swing, hang upside down, or perform exercises that would put you in danger.
- ◆ Never attach Versa-Band to an anchor point that cannot handle the weight being applied or to anchor points that can cause excessive wear and tear. Failure to do so could potentially cause severe and minor injury.

THANK YOU!

Want to be a Versa-Band Ambassador? Visit Versa-Band.com for additional information or contact us at Support@Versa-Band.com.

VERSA-BAND


By using Versa-Band you are accepting the responsibility of your actions and are hereby waiving any rights to legal action against Oz Unlimited, LLC.

Product Information



Our Mission:

To Provide Every Individual with the Opportunity to Workout Any Muscle Group, from Anywhere, Anytime!



Pro

Versa-Band
Two 15 lb
Resistance Bands
Two 20 lb
Resistance Bands
Two 30 lb
Resistance Bands
Ankle Straps
Belt Trainer
Main Anchor
Door Anchor
Carabiners
Drawstring Bag

Parts:

- A. Versa-Band Main Body with Center O-Ring, and Left and Right Straps. (1)
- B. D-Ring and Quick Release (2)
- C. Handles (2)
- D. Resistance Bands (#/size of bands vary*)
Additional Bands available at Versa-Band.com

Accessories:

- E. Door Anchor
- F. Main Carabiner (1)
- G. Main Anchor
- H. Ankle Straps *
- I. Belt Trainer *
- J. Drawstring Bag & Equipment Storage Band

#RELEASEYOURGRIP

Versa-Band's Main Body (A) is preassembled with one (1) O-Ring at the top and two (2) Straps, with a D-Ring and Quick Release Carabiner (B) attached to each end. Handles (C) then clip to the Quick Release.

Attach desired number of Resistance Bands (D) to the Main O-Ring (A), thread through the strap loops, and clip directly to the Handle (C) for each side. (Resistance Bands (D) vary in strength and can be combined for more resistance—see reverse for band sizes.)

Snap the Main Carabiner (F) onto the Main O-Ring (A) and attach either the Door Anchor (E) or Main Anchor (G) to secure Versa-Band to a sturdy anchor point. Review all safety guidelines before use.

*The Base Package includes one (1) set of Resistance Bands (15lb –Blue). Plus Package includes two (2) sets of Resistance Bands (15lb and 20lb-Green) and one (1) set of Ankle Straps (H). In addition to what comes with the Plus Package, Pro Packages include an additional set of Resistance Bands (30lb-Red) and a Belt Trainer (I). Ankle Straps and Belt Trainer are meant to be clipped directly to the Resistance Bands.



VERSA-BAND

IMAGINE WHAT YOU COULD DO WHEN YOU #RELEASEYOURGRIP



PROPER FOLDING AND STORAGE

Versa-Band conveniently stores into it's own **Drawstring Bag**. First, layout the **Main Body** (1), then overlap the left and right **Handles** so they rest on top of each other (2). From the **Main O-Ring**, where the **Main Anchor** is attached, fold down to the **Quick Release** (3), fold **Handles** back over (4), and slip the **Equipment Storage Band** (4) under the folded Versa-Band. Secure Versa-Band with the **Storage Band** (5) and tuck into the **Storage Bag**. (6).

